


SINGLE-ACTING, SPRING RETURN HYDRAULIC CYLINDERS



Item No.	Part No.	No. Req'd	Description
1	201375	1	Adapter (Grooved Saddle)
2	201376	1	Retainer Nut (Torque to 450/500 in. lbs.)
3	*201424	1	Rod Wiper
4	15122	1	Soc. Hd. Cap Screw (10-32 UNF X 5/8; Torque to 50/60 in. lbs.)
5	*14319	2	Copper Washer (3/16 X 5/16 X 1/32)
6	36092	1	Piston Rod (Model 100293)
	36093	1	Piston Rod (Model 100294)
7	16072	1	Round Retaining Ring
8	201377	1	Piston Head (Assemble with groove toward shoulder.)
9	*13426	1	U-cup Piston Seal
10	201373	1	Retainer Washer
11	*13653	1	Retainer Ring
12	201372	2	Spring Retainer
13	201422	1	Extension Spring (Model No. 100293)
	201423	1	Extension Spring (Model No. 100294) (Spring must not extend beyond threads of spring retainer [both ends]. Stretch, clean and lubricate before ass'y.)
14	38785	1	Cylinder Body (Model No. 100293)
	38786	1	Cylinder Body (Model No. 100294)
15	10479	1	Pipe Plug (1/4 NPTF)
16	10676	1	Pipe Bushing (3/8 to 1/4 NPTF)
17	16071	1	Soc. Hd. Cap Screw (10-32 UNF X 1" long; Torque to 50/60 in. lbs.)
	*14995	1	Trade Name Decal (Not Shown)

Part numbers marked with an asterisk (*) are contained in Repair Kit No. 300035.

Refer to any operating instructions included with this product for detailed information about operation, testing, disassembly, reassembly, and preventive maintenance.

Items found in this parts list have been carefully tested and selected. **Therefore: Use only genuine Hytec replacement parts!**

Additional questions can be directed to our Technical Services Department.