


Item No.	Part No.	No. Req'd	Description
1	16112	2	Machine Screw (3/8-16 UNC X 3/4 Lg.)
2	302651	1	Front Plate
3	45642	1	Locking Ring
4	45643	1	Retainer Nut (Torque to 90/100 ft. lbs. wet or dry)
5	52205	1	Threaded Piston
6	*12042	2	Copper Washer (9/16 X 3/8 X 1/32)
7	*19207	1	T-seal & Backup Rings (Smooth side of Backup Ring must be against seal.)
9	16110	2	Cap Screw (9/16 X 3/8 X 1/32; Torque to 400/425 in. lbs.)
10	9796	1	Ram Half Coupler w/ Plastic Dust Cap
11	10005	2	Cap Screw (1/4-20 UNC X 1/2 Lg.)
12	10244	2	Lockwasher (For 1/4 bolt)
13	35903BK2	1	Handle
14	52342	1	Cylinder Body
15	36084	2	Spring Retainer
16	201417	2	Spring Retainer
17	201475	1	Extension Spring
18	201474	1	Extension Spring

PARTS INCLUDED BUT NOT SHOWN

200056	1	Locknut Handle
251139	1	Trade Name Decal
*304937	1	Warning Decal
*37782	1	Warning Decal

Part numbers marked with an asterisk (*) are contained in Repair Kit No. 300396.

SPRING & RETAINER ASSEMBLY



Refer to any operating instructions included with this product for detailed information about operation, testing, disassembly, reassembly, and preventive maintenance.

Items found in this parts list have been carefully tested and selected. **Therefore: Use only genuine Power Team replacement parts!**

Additional questions can be directed to our Technical Services Department.

Note: Shaded areas reflect last revision(s) made to this form.