

Hydraulic Technologies
5885 11th Street
Rockford, IL 61109-3699 USA

Tech. Services: (800) 477-8326
Fax: (800) 765-8326
Order Entry: (800) 541-1418
Fax: (800) 288-7031

Internet Address:
<http://www.powerteam.com>

Parts List for:

110001
110002
110003

**SINGLE-ACTING (THREADED BODY)
SWING / PULL CLAMP**


Max. Capacity: 365 lbs. Clamping Force (with 1.06" lg. arm) at 5,000 PSI Max.

110001 - Left Hand

110002 - Right Hand

110003 - Straight Pull

The piston rod U-cup seal (Item 11) can be easily twisted if installed incorrectly. Before installing the piston rod (Item 15) lubricate the rod and all seals with hydraulic oil. Install the rod with light pressure and a twisting motion as the seal is first contacted.



Parts List, Form No. 101869, Back sheet 1 of 1

Item No.	Part No.	No. Req'd	Description
1	251910	1	Screw, Button HD (1/4-20 x 3/8; Torque to 80/100 in. lbs.)
2	252455	1	Plug, w/Filter
3	*252480	1	Washer, Backup (.56 x .45 x .04)
4	*252509	1	Washer, Special (.55 x .43) (NOTE: Assemble washer with larger radii towards teflon washer [Item #3]. Must be grease and oil free.)
5	351397	1	Cam, Left Hand (Left Hand† 90° for 110001)
	351398	1	Cam, Right Hand (Right Hand† 90° for 110002)
	351399	1	Cam, Straight (Straight Pull for 110003)
6	252454	1	Pin, Spring (.10 x .41)
7	351402	1	Cap, End SA (Torque to 230/250 in. lbs.)
8	351401	1	Body, Threaded w/Plug
9	252452	1	Spring (.54 OD x 1.94 x .06 WS)
10	*252478	1	Washer, Backup (.56 x .39 x .04)
11	*252470	1	U-Cup (.56 x .38 x .09 H)
12	*252473	1	U-Cup (.62 x .43 x .09 H)
13	*252479	1	Washer, Backup (.61 x .43 x .04)
14	*252453	1	Wiper, Rod (.69 x .44 URE)
15	351400	1	Rod, Piston

NOTE: Grease roller in piston rod (Item #15) and cam with a light coating of CDM Extreme Pressure Lube #3.

Part numbers marked with an asterisk (*) are contained in Repair Kit No. 300953.

† Right hand rotation is clockwise rotation when viewed from the piston rod end.

Left hand is counterclockwise rotation. To reverse clamp rotation, order the appropriate rotating cam.

Note: Shaded areas reflect last revision(s) made to this form.

Refer to any operating instructions included with this product for detailed information about operation, testing, disassembly, reassembly, and preventive maintenance.

Items found in this parts list have been carefully tested and selected. **Therefore: Use only genuine Hytec replacement parts!**

Additional questions can be directed to our Technical Services Department.