


**SPRING ADVANCE
WORK SUPPORT**
1,300 LBS. WITH BASE




Item No.	Part No.	No. Req'd	Description
1	250883	1	Fitting, Plug (1/4 Tube)
2	350794	1	Support, Spring Work 1100 Lb. (Torque to 85/95 ft. lbs.)
3	*251248	1	Washer, Backup (1.19 x 1.00)
4	421727	1	Base, Work Support
5	*251767	1	O-ring (.41 x .22 Nitrile)
6	*11496	1	O-ring (.49 x .35 Nitrile)

Part numbers marked with an asterisk (*) are contained in Repair Kit No. 300654.

WORK SUPPORT ASSEMBLY

HYDRAULIC SCHEMATIC



Item No.	Part No.	No. Req'd	Description
1	251397	1	Assembly, Vented Button
2	251242-1	1	Screw, Button Hd (6-32 x 5/8; Apply loctite 271 or equiv. adjust scw until piston is flush with adapter.)
3	251243	1	Spring (.24 OD x 2.79 x .02 WS)
4	*251247	1	Washer, Backup (.88 x .75)
5	*251246	1	O-ring (.88 x .75 Nitrile)
6	350733	1	Adapter, Spring
7	420706	1	Support, Plunger & Sleeve
8	420705	1	Body, Work Support
9	*12900	1	O-ring (1.00 x .87 Urethane)
10	*251254	1	Wiper, Rod (1.00 x .75 Nitrile)

Part numbers marked with an asterisk (*) are contained in Repair Kit No. 300654.