

Hydraulic Technologies  
5885 11th Street  
Rockford, IL 61109-3699 USA

Tech. Services: (800) 477-8326  
Fax: (800) 765-8326  
Order Entry: (800) 541-1418  
Fax: (800) 288-7031

Internet Address:  
<http://www.powerteam.com>

**Parts List for:**

**110176**  
**110177**  
**110178**

**Double-acting  
SWING / PULL CLAMP**


**Max. Capacity: 1,200 lbs. Clamping Force (with 1-1/2" Ig. arm) at 5,000 PSI**

**110176 - Left Hand, 11/32" Stroke**

**110177 - Right Hand, 11/32" Stroke**

**110178 - Straight Pull, 11/32" Stroke**

The piston rod U-cup seal (Item 12) can be easily twisted if installed incorrectly. Before installing the piston rod (Item 2) lubricate the rod and all seals with hydraulic oil. Install the rod with light pressure and a twisting motion as the seal is first contacted.


**SECTION A-A**

Sheet No. 1 of 1

Rev. Date: 10 Mar 2002

# Parts List, Form No. 108188, Back sheet 1 of 1

Item No.	Part No.	No. Req'd	Description
1	251445	1	Screw, Button Hd. (3/8-16 x 3/8 )
2	360156	1	Piston Rod
3	250961	2	O-ring Boss Plug (7/16-20 Plastic)
4	260137	2	Backup Washer (.87 x .70 )
5	*260139	1	O-ring (.87 x .68 Polyurethane)
6	*12745	1	O-ring (1.15 x .92 )
7	*260141	1	Rod Wiper
8	260144	1	Spring Pin (.13 x .60 )
9	360091	1	Rotating Cam (Left Hand† 90° for 110176)
	360092	1	Rotating Cam (Right Hand† 90° for 110177)
	360090	1	Rotating Cam (Straight Pull for 110178)
10	360086	1	End Cap
11	360154	1	Body, w/ Plug
12	*360156	1	U-cup
13	*260138	1	Backup Washer (.80 x .62 )

NOTE: Flat of cam (clamp stroke area) to be opposite of body port.  
Grease roller in piston rod (Item #2) and cam with a light coating of CDM Extreme Pressure Lube #3.

Part numbers marked with an asterisk (\*) are contained in Repair Kit No. 301039.

†Right hand rotation is clockwise rotation when viewed from the piston rod end. Left hand is counterclockwise rotation. To reverse clamp rotation, order the appropriate rotating cam.

Refer to any operating instructions included with this product for detailed information about operation, testing, disassembly, reassembly, and preventive maintenance.

Items found in this parts list have been carefully tested and selected. **Therefore: Use only genuine Hytec replacement parts!**

Additional questions can be directed to our Technical Services Department.